

## CONNECTING YOUR DIGITAL CONVERTER BOX

- 1** Connect the antenna to the ATSC (RF IN) jack on the back of your converter box.
- 2** Using the supplied RF Coax Cable, connect the NTSC (RF OUT) jack on the back of your converter box to the ANTENNA IN jack on the back of your TV.  
(NOTE: You may also connect converter box to TV with optional RCA Audio/Video Cable)
- 3** Connect the power cord into a power outlet or surge protector.
- 4** Turn ON the converter box and TV.
- 5** Set your TV to Channel 3 (or 4) to match the CH3/CH4 switch on the back of the converter box.

# Initial Setup Menu

## Please verify the following:

- The batteries are correctly installed in the Access HD remote control.
- The TV is ON and the digital converter box is powered ON (Green LED/Light lit on front panel)
- The converter box and your TV are both set to Channel 3 (or both 4).



### 1. Set the Menu Language:

- Press ▶ to set your Language (English, Spanish, French)




### 2. Set the Time Zone:

- Press ▼ to select Time Setup
- Press ▶ to set your Time Zone (Pacific, Alaska, Hawaii, Eastern, Central, Mountain)



### 3. Auto Program Channels:

- Press ▼ to select Auto Channel Searching
  - Press ▶ to begin automatically searching for channels
- It will Perform a Fast Scan (1-2 minutes)



- It will then Perform a Digital (Deep) Scan (4-6 minutes)



- Please be patient, as this complete process takes from 5 to 8 minutes
- DO NOT INTERRUPT THE PROCESS
- Once the Auto Channel Searching is finished, it will automatically exit and display the first channel found